

T2 PROFESSIONAL DISC GOLF PORTABLE
TARGET ASSEMBLY INSTRUCTIONS

Bolt

2 x	A	


Washer

2 x	B	

Nut

2 x	C	


Set Screw

6 x	D	

Allen Wrench

1 x	

WWW.PRODIGYDISC.COM



PRODIGY

T2 PROFESSIONAL DISC GOLF PORTABLE TARGET ASSEMBLY INSTRUCTIONS

1. Remove powder-coated set screws from holes (X), (Y) and (Z) and discard.

2. Place base on flat ground. Insert bottom pole with no holes in the base. Insert 2 new set screws (D) and tighten.

3. Slide basket over pole, and down until the hole and pole hole line up.

4. Insert bolt(A) through basket and pole holes.

5. Level the basket, then screw in two of the set screws (D) using the provided allen wrench to tighten the poles and basket into place.

6. Add washer (B) and nut (C) to bolt (A) then tighten down on the basket.

7. To install top assembly, slide center ring of chains over top pole followed by top band.

8. Insert bolt (A) through the large hole from the top on band assembly, then screw on washer (B) and nut (C). Secure top band in place by screwing in two set screws (D).

WWW.PRODIGYDISC.COM